



UNION CORPORATION JAPAN

www.elmesworld.com

ELMES INC.

19142 South Van Ness Avenue Torrance,


CA 90501 USA

Toll Free: (877) 356-3737

Tel: (310) 618-8870 Fax: (310) 618-8874

Elmes Door Handing Reference Chart

DOOR HANDING - U.S. STANDARDIZATION PROCEDURE



The door handing (left or right) is determined from exterior or outside of door (secure/key side). Exterior and interior handles are defined as follows:

Exterior : handles cannot be dismantled from the outside.

Interior : door handles can be dismantled since the fasteners are exposed.